

THE  
**aarhus**  
SYSTEM™

Driver Assembly Instructions



REV 7/13

# Driver Assembly Instructions

**Screw Release Sleeve**  
907.50.07



**Screwdriver Blade**  
75.23.39



**Extended Sleeve**  
907.50.08



**Extended Blade**  
75.23.91




## Screwdriver Handle Options

75.23.50




75.23.78A



*NOTE: Screwdriver handles will accept either the Standard Blade/Sleeve or the Extended Blade/Sleeve.*

## Assembled Blade and Sleeve



**1. Slide Sleeve onto Blade**



**2. Twist to engage threads**



**3. Retract and Hold**



**4. Slide assembly completely into handle end**



**5. Release to lock assembly in place**